















●: Incluido - ○: Opcional - ⊗: Incompatible

	R.1021	RKE.1412	RNE.1612	RAE.2102	RAE.2102.Racing	RAE.2108	RASE.2124	RASE.TOP.2125	RASE.TOP.2132	RASE.TOP.3030
 Desmontable	●	●	●	●	●	●	●	●	●	⊗
 Desmontable corto para LL	⊗	⊗	⊗	⊗	⊗	⊗	⊗	●	●	●
 Grupo repartidor	⊗	●	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗
 Lubricador	⊗	○	●	⊗	⊗	⊗	⊗	⊗	⊗	⊗
 Lubricador + regulador de presión con filtro y manómetro SRA063901400	●	○	○	●	●	●	●	●	●	●
  Protecciones uñeta SRA007204100 SRA007204200	●	●	●	●	●	●	●	⊗	⊗	⊗
 Protecciones garras SRA007201800	○	○	○	●	●	●	⊗	⊗	⊗	⊗

 <p>protecciones garras completas</p>	○	○	○	○	○	○	○	●	⊗	⊗	⊗
 <p>protecciones garras</p>	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	●	●	●
 <p>protecciones</p>	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	⊗	●
 <p>Protección desmontable SRA007201700</p>	●	□	□	●	●	●	■	■	■	■	⊗
 <p>Protección pala destalonador</p>	●	○	○	●	●	●	●	●	●	●	⊗
 <p>Brocha para lubricante de montaje SRA040000100</p>	●	□	●	●	●	●	●	●	●	●	●

 <p>Inflador</p>	●	○	○	●	●	●	●	●	⊗	⊗
 <p>Cubo lubricante de montaje</p>	●	○	○	○	○	○	●	●	●	●
 <p>Autocentrante 22"</p>	⊗	○	○	○	⊗	●	⊗	⊗	⊗	⊗
 <p>Autocentrante 24"</p>	⊗	○	○	○	●	○	●	●	●	⊗